



3472 Highway 5
Douglasville, GA 30135
770-942-0118

"Your Leader in Backyard Vacation Fun"

WEEKLY POOL MAINTENANCE Mineral Springs / Aqua Logic

1. Leave main switch on **Mineral Springs** unit set to "AUTO".
2. Run pump minimum of 10-12 hours per day to ensure adequate filtration and activity of the Mineral Springs/Aqua Logic unit.
3. Backwash sand filter, or clean cartridge filter(s)
4. Clean out debris from skimmer basket.
5. Check pump basket for debris.
6. Test for free chlorine.
Maintain free chlorine at 1-3 ppm by adjusting the sanitizer output control on the Mineral Springs or Aqua Logic unit.
7. Test pH (Maintain pH at 7.4-7.6. Adjust as needed)
8. Add _____ bag(s) **Mineral Springs Renewal** (1 lb/5,000 gal)
(Minerals can be lost through backwashing, dilution and splash out)
9. Brush the walls and the bottom of the pool.
10. Clean the water line with **OFF THE WALL**.
11. Vacuum as needed.
12. Run Automatic Cleaner for 2 hours, 2-3 times each week.
13. Before you bring water sample to Brown's Pools for analysis, please obtain mineral reading so you can advise ppm reading to Water Analyst.

During high bather loads, large amounts of rain or cloudy water, put the main switch in the SANITIZER BOOST position for 24 hours. Put switch back to "AUTO" position.

Brown's Pools Water Analyst

Date of Analysis